

VGN-S54B/S94PS/S94S
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P
VGN-S5HP/S5M/S5VP/S5XP
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP


SERVICE MANUAL

Ver. 2 2005I

Revision History

Area	Model	Lineup
Japanese	Japanese	VGN-S54B/S VGN-S94PS VGN-S94PS* VGN-S94S*
American	US Canadian	VGN-S550P/S VGN-S560P/B VGN-S570P/S VGN-S580* VGN-S580B* VGN-S580BH* VGN-S580P*
European	AEP/UK	VGN-S5HP/B VGN-S5M/S VGN-S5VP/B VGN-S5XP/B
Asia/Oceania/ South Africa	International	VGN-S54GP/S VGN-S55SP/S VGN-S56GP/S VGN-S57SP/B VGN-S58GP/B
	Chinese	VGN-S55C/S VGN-S55CP/S VGN-S56C/B VGN-S56C/S VGN-S56CP/B VGN-S56CP/S VGN-S58CP/B VGN-S59CP/B

* : CTO Model



· Design and specifications are subject to change without notice.

· 本機の仕様および外観は、改良のため予告なく変更することがありますが、ご了承ください。

PERSONAL COMPUTER

SONY®

Information in this document is subject to change without notice.

Sony, VAIO and CLIE are trademarks or registered trademarks of Sony. Microsoft, Windows, Windows Media, Outlook, Bookshelf and other Microsoft products are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries. The word Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG, Inc. AMD, the AMD logo, other AMD product names and combinations thereof are trademarks of Advanced Micro Devices, Inc. Intel Inside logo, Pentium and Celeron are trademarks or registered trademarks of Intel Corporation. Transmeta, the Transmeta logo, Crusoe Processor, the Crusoe logo and combinations thereof are trademarks of Transmeta Corporation in the USA and other countries. Graffiti, HotSync, PalmModem, and Palm OS are registered trademarks, and the Hotsync logo and Palm are trademarks of Palm, Inc. or its subsidiaries. (M) and Motrola are trademarks of Motrola, Inc. Other Motrola products and services with (R) mark like Dragomball are the trademarks of Motrola, Inc.

All other names of systems, products and services in this manual are trademarks or registered trademarks of their respective owners. In this manual, the (TM) or (R) mark are not specified.

Caution Markings for Lithium/Ion Battery - The following or similar texts shall be provided on battery pack of equipment or in both the operating and the service instructions.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

CAUTION: The battery pack used in this device may present a fire or chemical burn hazard if mis-treated. Do not disassemble, heat above 100°C (212°F) or incinerate. Dispose of used battery promptly. Keep away from children.

CAUTION: Changing the back up battery.

- Overcharging, short circuiting, reverse charging, mutilation or incineration of the cells must be avoided to prevent one or more of the following occurrences; release of toxic materials, release of hydrogen and/or oxygen gas, rise in surface temperature.
- If a cell has leaked or vented, it should be replaced immediately while avoiding to touch it without any protection.

Service and Inspection Precautions

1. Obey precautionary markings and instructions

Labels and stamps on the cabinet, chassis, and components identify areas requiring special precautions. Be sure to observe these precautions, as well as all precautions listed in the operating manual and other associated documents.

2. Use designated parts only

The set's components possess important safety characteristics, such as noncombustibility and the ability to tolerate large voltages. Be sure that replacement parts possess the same safety characteristics as the originals. Also remember that the $\triangle$ mark, which appears in circuit diagrams and parts lists, denotes components that have particularly important safety functions; be extra sure to use only the designated components.

3. Always follow the original design when mounting parts and routing wires

The original layout includes various safety features, such as inclusion of insulating materials (tubes and tape) and the mounting of parts above the printer board. In addition, internal wiring has been routed and clamped so as to keep it away from hot or high-voltage parts. When mounting parts or routing wires, therefore, be sure to duplicate the original layout.

4. Inspect after completing service

After servicing, inspect to make sure that all screws, components, and wiring have been returned to their original condition. Also check the area around the repair location to ensure that repair work has caused no damage, and confirm safety.

5. When replacing chip components...

Never reuse components. Also remember that the negative side of tantalum capacitors is easily damaged by heat.

6. When handling flexible print boards...

- The temperature of the soldering-iron tip should be about 270°C.
- Do not apply the tip more than three times to the same pattern.
- Handle patterns with care; never apply force.

Caution: Remember that hard disk drives are easily damaged by vibration. Always handle with care.

**ATTENTION AU COMPOSANT AYANT
RAPPORT
À LA SÉCURITÉ!**
**LES COMPOSANTS IDENTIFIÉS PAR UNE
MARQUE $\triangle$ SUR LES DIAGRAMMES
SCHÉMATIQUES ET LA LISTE DES PIÈCES
SONT CRITIQUES POUR LA SÉCURITÉ DE
FONCTIONNEMENT. NE REMPLACER CES
COMPOSANTS QUE PAR DES PIÈCES SONY
DONT LES NUMÉROS SONT DONNÉS
DANS CE MANUEL OU DANS LES
SUPPLÉMENTS PUBLIÉS PAR SONY.**

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
CHAPTER 1. SPECIFICATIONS			CHAPTER 5. OTHERS		
1-1. Specifications		1-1	5-1. The Barcode Label		5-1
		(to 1-2)	5-2. Replacing the CPU		5-2
					(to 5-2)
CHAPTER 2. BLOCK DIAGRAM		2-1			
		(to 2-1)			
CHAPTER 3. FRAME HARNESS DIAGRAM		3-1			
		(to 3-1)			
CHAPTER 4. EXPLODED VIEWS AND PARTS LIST					
How to identify the VGN-S90PS.....		4-2			
Palmrest					
P-1		4-3			
Main Board					
M-1		4-5			
Bottom					
B-1		4-7			
LCD					
L-1. 13.3-inch WXGA (Brighter) – Made by TO –		4-9			
L-2. 13.3-inch WXGA.....		4-11			
L-3. 13.3-inch WXGA (Brighter) – Made by SH –		4-13			
Accessories					
A-1.....		4-15			
		(to 4-15)			

History of the changes is shown as the "Revision History" at the end of this data.

変更履歴は、“Revision History”として、本データ末に記載してあります。

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

CHAPTER 1.

SPECIFICATIONS

1-1. Specifications

Model	J				AM					
	VGN-S54B/S	VGN-S94PS (28199212)	VGN-S94PS*	VGN-S94S*	VGN-S560P/B	VGN-S570P/S	VGN-S550P/S	VGN-S580*	VGN-S580P*	
CPU	PM/Do/740/1.73GHz	PM/Do/740/1.73GHz	Cel/Do/370/1.50GHz or PM/Do/740/1.73GHz or PM/Do/760/2GHz or PM/Do/780/2.26GHz	Cel/Do/370/1.50GHz or PM/Do/740/1.73GHz or PM/Do/760/2GHz or PM/Do/780/2.26GHz	PM/Do/750/1.86GHz	PM/Do/750/1.86GHz	PM/Do/740/1.73GHz	Cel/Do/370/1.50GHz or PM/Do/740/1.73GHz or PM/Do/750/1.86GHz or PM/Do/760/2GHz or PM/Do/770/2.13GHz or PM/Do/780/2.26GHz	Cel/Do/370/1.50GHz or PM/Do/740/1.73GHz or PM/Do/750/1.86GHz or PM/Do/760/2GHz or PM/Do/770/2.13GHz or PM/Do/780/2.26GHz	
Chipset	Intel 915GM	Intel 915PM	Intel 915GM or Intel Intel 915GM Integrated or NVIDIA NV44M (TC32MB)	Intel 915GM or Intel Intel 915GM Integrated or NVIDIA NV44M (TC32MB)	Intel 915PM	Intel 915PM	Intel 915GM	Intel 915GM or Intel Intel 915GM Integrated or NVIDIA NV44M (TC32MB)	Intel 915GM or Intel Intel 915GM Integrated or NVIDIA NV44M (TC32MB)	
Graphics	Intel 915GM Integrated	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	Intel 915GM Integrated	Intel 915GM Integrated or NVIDIA NV44M (TC32MB)	Intel 915GM Integrated or NVIDIA NV44M (TC32MB)	
LCD	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR or 13.3/WXGA	13.3/WXGA/BR or 13.3/WXGA	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR	
HDD	80GB	80GB	100GB or 40GB or 60GB or 80GB or 120GB	100GB or 40GB or 60GB or 80GB or 120GB	100GB	100GB	80GB	100GB or 40GB or 60GB or 80GB or 120GB	100GB or 40GB or 60GB or 80GB or 120GB	
Memory Std	256MB(256MBx1)	1GB(512MBx2)	2GB(1GBx2) or 1GB(512MBx2) or 512MB(256MBx2) or 256MB(256MBx1)	2GB(1GBx2) or 1GB(512MBx2) or 512MB(256MBx2) or 256MB(256MBx1)	512MB(512MBx1)	512MB(512MBx1)	512MB(512MBx1)	2GB(1GBx2) or 1GB(1GBx1) or 1GB(512MBx2) or 512MB(512MBx1) or 512MB(256MBx2) or 256MB(256MBx1)	2GB(1GBx2) or 1GB(1GBx1) or 1GB(512MBx2) or 512MB(512MBx1) or 512MB(256MBx2) or 256MB(256MBx1)	
Memory Max	2GB	2GB	2GB	2GB	2GB	2GB	2GB	2GB	2GB	
Optical	SuperMulti/9.5/x4+DL	SuperMulti/9.5/x4+DL	Combo/9.5/x24 or SuperMulti/9.5/x4+DL	Combo/9.5/x24 or SuperMulti/9.5/x4+DL	DVD+-RW/9.5/x4+DL	DVD+-RW/9.5/x4+DL	DVD+-RW/9.5/x4+DL	Combo/9.5/x24 or DVD+-RW/9.5/x4+DL	Combo/9.5/x24 or DVD+-RW/9.5/x4+DL	
Wireless LAN	802.11abg/Intel/mPCI	802.11abg/Intel/mPCI	802.11abg/Intel/mPCI	802.11abg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11abg/Intel/mPCI or 802.11bg/Intel/mPCI	802.11abg/Intel/mPCI or 802.11bg/Intel/mPCI	
AC adaptor	VGP-AC19V11	VGP-AC19V11	VGP-AC19V11	VGP-AC19V11	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10	
Battery	VGP-BPS2	VGP-BPS2	VGP-BPL2 or VGP-BPS2	VGP-BPL2 or VGP-BPS2	VGP-BPS2	VGP-BPS2	VGP-BPS2	VGP-BPL2 or VGP-BPS2	VGP-BPL2 or VGP-BPS2	
Bluetooth	x	○	○	○	x	x	x	○ or x	○ or x	
Felica	○	○	○	○	○	○	○	x	x	
OS	XP Home	XP Pro	XP Pro	XP Home	XP Pro	XP Pro	XP Pro	XP Home	XP Pro	
Color Variation	Silver	Silver	Silver or Black	Silver or Black	Black	Black	Silver	Black	Black	
Office	XP Personal	None	XP Personal or XP Pro or None	XP Personal or XP Pro or None	None	None	None	None	None	
Keyboard	Japanese	Japanese	English or Japanese	English or Japanese	English	English	English	English	English	

Model	AM				EU					
	VGN-S580B*	VGN-S580BH*			VGN-S5XP/B	VGN-S5VP/B	VGN-S5HP/B	VGN-S5M/S		
CPU	Cel/Do/370/1.50GHz or Do/740/1.73GHz or PM/Do/750/1.86GHz or PM/Do/760/2GHz or PM/Do/770/2.13GHz or PM/Do/780/2.26GHz	Cel/Do/370/1.50GHz or PM/Do/740/1.73GHz or PM/Do/750/1.86GHz or PM/Do/760/2GHz or PM/Do/770/2.13GHz or PM/Do/780/2.26GHz			PM/Do/760/2GHz	PM/Do/770/2.13GHz	PM/Do/740/1.73GHz	PM/Do/740/1.73GHz		
Chipset	Intel 915GM or Intel Intel 915GM Integrated or NVIDIA NV44M (TC32MB)	Intel 915GM or Intel Intel 915GM Integrated or NVIDIA NV44M (TC32MB)			Intel 915PM	Intel 915PM	Intel 915PM	Intel 915PM		
Graphics	Intel 915GM Integrated or NVIDIA NV44M (TC32MB)	Intel 915GM Integrated or NVIDIA NV44M (TC32MB)			NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)		
LCD	13.3/WXGA/BR	13.3/WXGA/BR			13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR		
HDD	100GB or 40GB or 60GB or 80GB or 120GB	100GB or 40GB or 60GB or 80GB or 120GB			100GB	120GB	80GB	80GB		
Memory Std	2GB(1GBx2) or 1GB(1GBx1) or 1GB(512MBx2) or 512MB(512MBx1) or 512MB(256MBx2) or 256MB(256MBx1)	2GB(1GBx2) or 1GB(1GBx1) or 1GB(512MBx2) or 512MB(512MBx1) or 512MB(256MBx2) or 256MB(256MBx1)			1GB(1GBx1)	1GB(1GBx1)	512MB(512MBx1)	512MB(512MBx1)		
Memory Max	2GB	2GB			2GB	2GB	2GB	2GB		
Optical	Combo/9.5/x24 or DVD+-RW/9.5/x4+DL	Combo/9.5/x24 or DVD+-RW/9.5/x4+DL			DVD+-RW/9.5/x4+DL	DVD+-RW/9.5/x4+DL	DVD+-RW/9.5/x4+DL	DVD+-RW/9.5/x4+DL		
Wireless LAN	802.11abg/Intel/mPCI or 802.11bg/Intel/mPCI	802.11abg/Intel/mPCI or 802.11bg/Intel/mPCI			802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI		
AC adaptor	VGP-AC19V10	VGP-AC19V10			VGP-AC19V10	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10		
Battery	VGP-BPL2 or VGP-BPS2	VGC-BPL2 or VGC-BPS2			VGP-BPS2	VGP-BPS2	VGP-BPS2	VGP-BPS2		
Bluetooth	○ or x	○ or x			○	○	○	○		
Felica	x	x			x	x	x	x		
OS	XP Pro	XP Home			XP Pro	XP Pro	XP Pro	XP Home		
Color Variation	Black	Black			Black	Black	Black	Silver		
Office	None	None			None	None	None	None		
Keyboard	English	English			-	-	-	-		

△ [MA]

△ [MA]

△ [MA]

△ [MA]

△ [MA]

- The trademarks of registered trademarks of above table, refer to page 2.
- The model that is accompanied by asterisk (*) is the CTO model.
- As for the S94PS, check the Page 4-2 of "How to identify the VGN-S94PS", then refer to the Specifications.
- 表中の商標・登録商標については、2ページをご参照ください。
- 機種名に (*) がつくものはCTOモデルです。
- S94PSは4-2ページの"VGN-S94PSの判断方法"を確認してからSpecificationsをご参照ください。

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

AO								
Model	VGN-S59CP/B	VGN-S58CP/B	VGN-S58CP/B	VGN-S58CP/S	VGN-S56C/B	VGN-S56C/S	VGN-S55CP/S	VGN-S55C/S
CPU	PM/Do/780/2.26GHz	PM/Do/770/2.13GHz	PM/Do/750/1.86GHz	PM/Do/750/1.86GHz	PM/Do/750/1.86GHz	PM/Do/750/1.86GHz	PM/Do/740/1.73GHz	PM/Do/740/1.73GHz
Chipset	Intel 915PM	Intel 915PM	Intel 915PM	Intel 915PM	Intel 915PM	Intel 915PM	Intel 915GM	Intel 915GM
Graphics	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	NVIDIA NV44M (TC32MB)	Intel 915GM Integrated	Intel 915GM Integrated
LCD	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR	13.3/WXGA/BR
HDD	100GB	60GB	40GB	40GB	40GB	40GB	40GB	40GB
Memory Std	512MB(512MBx1)	512MB(512MBx1)	512MB(512MBx1)	512MB(512MBx1)	512MB(512MBx1)	512MB(512MBx1)	256MB(256MBx1)	256MB(256MBx1)
Memory Max	2GB	2GB	2GB	2GB	2GB	2GB	2GB	2GB
Optical	DVD+-RW/9.5/x4/+DL	DVD+-RW/9.5/x4/+DL	DVD+-RW/9.5/x4/+DL	DVD+-RW/9.5/x4/+DL	Combo/9.5/x24	Combo/9.5/x24	Combo/9.5/x24	Combo/9.5/x24
Wireless LAN	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI	802.11bg/Intel/mPCI
AC adaptor	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10	VGP-AC19V10
Battery	VGP-BPS2	VGP-BPS2	VGP-BPS2	VGP-BPS2	VGP-BPS2	VGP-BPS2	VGP-BPS2	VGP-BPS2
Bluetooth	O	O	O	O	O	O	O	O
Felica	x	x	x	x	x	x	x	x
OS	XP Pro	XP Pro	XP Pro	XP Pro	XP Home	XP Home	XP Pro	XP Home
Color Variation	Black	Black	Black	Black	Silver	Silver	Silver	Silver
Office	None	None	None	None	None	None	None	None
Keyboard	English	English	English	English	English	English	English	English

AO							
Model	VGN-S58GP/B		VGN-S57SP/B		VGN-S56GP/S		VGN-S55SP/S
CPU	PM/Do/770/2.13GHz		PM/Do/770/2.13GHz		PM/Do/750/1.86GHz		PM/Do/750/1.86GHz
Chipset	Intel 915PM		Intel 915PM		Intel 915PM		Intel 915PM
Graphics	NVIDIA NV44M (TC32MB)		NVIDIA NV44M (TC32MB)		NVIDIA NV44M (TC32MB)		NVIDIA NV44M (TC32MB)
LCD	13.3/WXGA/BR		13.3/WXGA/BR		13.3/WXGA/BR		13.3/WXGA/BR
HDD	80GB		80GB		60GB		60GB
Memory Std	512MB(512MBx1)		512MB(512MBx1)		512MB(512MBx1)		512MB(512MBx1)
Memory Max	2GB		2GB		2GB		2GB
Optical	DVD+-RW/9.5/x4/+DL		DVD+-RW/9.5/x4/+DL		DVD+-RW/9.5/x4/+DL		DVD+-RW/9.5/x4/+DL
Wireless LAN	802.11bg/Intel/mPCI		802.11bg/Intel/mPCI		802.11bg/Intel/mPCI		802.11bg/Intel/mPCI
AC adaptor	VGP-AC19V10		VGP-AC19V10		VGP-AC19V10		VGP-AC19V10
Battery	VGP-BPS2		VGP-BPS2		VGP-BPS2		VGP-BPS2
Bluetooth	O		x		O		x
Felica	x		x		x		x
OS	XP Pro		XP Pro		XP Pro		XP Pro
Color Variation	Black		Black		Silver		Silver
Office	None		None		None		None
Keyboard	English		English		English		English

AO			
Model	VGN-S54GP/S		
CPU	PM/Do/750/1.86GHz		
Chipset	Intel 915PM		
Graphics	NVIDIA NV44M (TC32MB)		
LCD	13.3/WXGA/BR		
HDD	40GB		
Memory Std	512MB(512MBx1)		
Memory Max	2GB		
Optical	Combo/9.5/x24		
Wireless LAN	802.11bg/Intel/mPCI		
AC adaptor	VGP-AC19V10		
Battery	VGP-BPS2		
Bluetooth	O		
Felica	x		
OS	XP Pro		
Color Variation	Silver		
Office	None		
Keyboard	English		

- The trademarks of registered trademarks of above table, refer to page 2.
- 本表中の商標・登録商標については、2ページをご参照ください。




Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580P (AM)
VGN-S55HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

CHAPTER 2.

BLOCK DIAGRAM




Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

CHAPTER 3.

FRAME HARNESS DIAGRAM



Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)


CHAPTER 4.

EXPLODED VIEWS AND PARTS LIST

• The parts list is compiled by blocks of a palmrest and bottom etc.
The sections of the parts list are different depending on the model.
Please refer to list of contents shown in the below.

• 分解図と部品表は、パームレスト、ボトムなどのブロックごとに分かれていま
す。機種によって部品表のセクションが異なりますので、詳細は右下の一覧表
を参照してください。

Section	Page
How to identify the VGN-S94PS	4-2
Palmrest	
P-1	4-3
Main Board	
M-1	4-5
Bottom	
B-1	4-7
LCD	
L-1, 13.3-inch WXGA (Brighter) – Made by TO –	4-9
L-2, 13.3-inch WXGA.....	4-11
L-3, 13.3-inch WXGA (Brighter) – Made by SH –	4-13 △ [MA]
Accessory	
A-1	4-15



NOTE:

- Items marked "" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- When two or more parts are shown, use the part described first as the main part.
- The parts marked "\$" are the High Value Modules (HVM).
- The parts marked "#" are the parts on which barcode label is attached. For the barcode label, refer to CHAPTER 5.
- The parts marked "&" are the "Customer Replaceable Parts (CRP)" that can be replaced by Field Customer Support.
- Especially the parts with the "<&>" mark require the special attention to use them. Here fore, check first whether the desired part is one of the targetted parts of the Customer Replaceable Parts (CRP), or the non-targetted parts by referring to the exploded view.

【使用上の注意】

- *印の部品は常備在庫しておりません。
- 図面番号のない部品は供給しません。
- 併記部品の場合、上部記載部品をメイン部品として使用してください。
- 部品名称の前に\$印のついた部品は、High Value Module (HVM) です。
- 商品名称の前に#印のついた部品は、バーコードラベル貼付部品です。バーコードラベルについてはCHAPTER 5を参照してください。
- 部品名称の前に&印のついた部品は、お客様窓口などでも交換可能なCustomer Replaceable Part (CRP) です。
- 特に<&>のついた部品は、使い分けが必要な部品ですので、分解図でCustomer Replaceable Parts対象部品が、対象外部品かを必ず御確認ください。

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

△印の部品、または△印付きの点線で囲まれた部品は、安全性を維持するために重要な部品です。従って交換時は、必ず指定の部品を使用して下さい。

△ [MA]
△ [MA]
△ [MA]
△ [MA]

△ [MA]
△ [MA]
△ [MA]
△ [MA]
△ [MA]
△ [MA]
△ [MA]
△ [MA]

△ [MA]

△ [MA]

△ [MA]
△ [MA]
△ [MA]

		Palmrest	Main Board	Bottom	LCD	Accessory
J	S54B/S	P-1	M-1	B-1	L-1	A-1
	S94S*	P-1	M-1	B-1	L-1, 2	A-1
	S94PS	P-1	M-1	B-1	L-1	A-1
	S94PS*	P-1	M-1	B-1	L-1, 2	A-1
AM	S560P/B	P-1	M-1	B-1	L-1	A-1
	S570P/S	P-1	M-1	B-1	L-1	A-1
	S550P/S	P-1	M-1	B-1	L-1	A-1
	S580*	P-1	M-1	B-1	L-1	A-1
	S580P*	P-1	M-1	B-1	L-1	A-1
	S580B*	P-1	M-1	B-1	L-1	A-1
EU	S580BH*	P-1	M-1	B-1	L-1	A-1
	S5XP/B	P-1	M-1	B-1	L-1	A-1
	S5VP/B	P-1	M-1	B-1	L-1	A-1
	S5HP/B	P-1	M-1	B-1	L-1	A-1
	S5M/S	P-1	M-1	B-1	L-3	A-1
AO	S59CP/B	P-1	M-1	B-1	L-1	A-1
	S58CP/B	P-1	M-1	B-1	L-1	A-1
	S56CP/B	P-1	M-1	B-1	L-1	A-1
	S56CP/S	P-1	M-1	B-1	L-1	A-1
	S56C/B	P-1	M-1	B-1	L-1	A-1
	S56C/S	P-1	M-1	B-1	L-1	A-1
	S55CP/S	P-1	M-1	B-1	L-1	A-1
	S55C/S	P-1	M-1	B-1	L-1	A-1
	S58GP/B	P-1	M-1	B-1	L-1	A-1
	S57SP/B	P-1	M-1	B-1	L-1	A-1
	S56GP/S	P-1	M-1	B-1	L-1	A-1
	S55SP/S	P-1	M-1	B-1	L-1	A-1
	S54GP/S	P-1	M-1	B-1	L-1	A-1

* : CTO model

Sony Confidential


VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580P/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

How to identify the VGN-S94PS
VGN-S94PSの判別方法

As for the S94PS, check the product code with the set , then refer to the corresponding section of the parts list and select the parts to be used.

S94PSはセットでProduct Codeを確認してから、部品表の該当箇所を参照し、使用する部品を選択してください。

【How to identify the VGN-S94PS】
【Serial No.の確認方法】



【Example of Parts List】
【部品表記載例】

Case of "28199212" Product code : Refer to the line a.
Case of except "28199212" Product code: refer to the line b.


Product Codeが"28199212"の場合 : a列を参照
Product Codeが"28199212"以外の場合 : b列を参照

			J				AM						
			S54B/S	S94PS (28199212)	S94PS*	S94S*	S560P/B	S570P/S	S550P/S	S580*	S580P*	S580B*	S560FP
Ref.No.	Part No.	Description											
2	X-2067-473-1	S3 ASSY PALMREST B					●			●	●	●	●
	X-2067-474-1	S3 ASSY PALMREST BF			●	●							
	X-2067-475-1	S3 ASSY PALMREST S						●	●				
	X-2067-476-1	S3 ASSY PALMREST SF	●	●	●	●							
10	2-638-893-01	S3 PANEL LED PALM		●	●	●				●	●	●	
	2-638-893-21	S3 PANEL LED PALM	●				●	●	●	●	●	●	●
				↑	↑								
				a	b								

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S55HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

P-1. Palmrest



Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S55HP/S55M/S55VP/S55XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

P-1. Palmrest

Ref. No.	Part No.	Description
3	1-830-870-11	CABLE, FLEXIBLE FLAT
4	1-830-872-11	CABLE, FLEXIBLE FLAT
5	1-831-344-11	CABLE, FLEXIBLE FLAT (12PIN)
6	1-831-352-11	CABLE, FLEXIBLE FLAT (16PIN)
7	A-1149-427-A	\$ COMPLETE PWB LEX-71 (S)
8	A-1149-428-A	\$ COMPLETE PWB SWX-208 (S)
9	A-1149-429-A	\$ COMPLETE PWB SWX-207 (S)
11	2-638-894-01	S3 COVER PALM
12	4-654-440-41	& CUSHION (PALM)
13	4-662-881-02	CUSHION, KEY BOARD
16	1-825-846-31	SPEAKER WITH BOX (L)
17	1-825-846-41	SPEAKER WITH BOX (R)
18	4-683-214-02	SWITCH WL
20	X-2067-472-1	S3 ASSY HOLDER TP
23	2-592-270-11	SHEET FFC
24	2-548-550-01	SHIELD MEMORY PLATE
B1	4-672-834-71	SCREW, +B EG GRIP
B2	4-676-936-01	+SCREW,O2 +SPECIAL HEAD SELF S

Ref No.	Part No.	Description	J												AM												EU												AO																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																										
			S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS	S94PS


- This parts list contains two different types of parts.
The first type is the parts that are common to all models.
The other type is the parts that are different depending on each model.
- As for the S94PS, check the Page 4-2 of "How to identify the VGN-S94PS" for S94PS, then refer to the Parts list.

- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- S94PSは4-2ページの"VGN-S94PSの判別方法"を確認してから、部品表をご参照ください。

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

M-1.Main Board



- 1 Ref. No. 335 is part used only for Ref. No. 305: A-1149-424-A.
- 2 Ref. No. 333 is part used only for Ref. No. 305: A-1149-423-A.
- 1 Ref. No. 335は、Ref. No. 305 : A-1149-424-Aのみに使用する部品です。
- 2 Ref. No. 333は、Ref. No. 305 : A-1149-423-Aのみに使用する部品です。

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580B/S580BH/S580P (AM)
VGN-S55HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

M-1.Main Board

Ref. No.	Part No.	Description
13	4-662-881-02	CUSHION, KEY BOARD
22	4-672-493-01	COVER (SC)
301	1-756-544-11	LITHIUM RECHARGEABLE BATTERY
304	1-417-539-12	CARD, MODEM
307	A-1151-384-A	COMPLETE PWB IFX-385 (S)
		#
		\$
310	1-794-548-21	CONNECTOR, USB(A)
312	1-787-301-21	FAN,DC(5V)
314	1-962-758-21	HARNESS ,RJ-45/21
315	2-580-414-01	HEATSINK UNIT
319	4-655-326-01	OFF, STAND
320	2-580-415-01	SHEET THERMAL
321	2-059-468-02	SHEET MDC
324	2-109-080-02	SHEET RJ-CON
325	2-059-469-02	SHEET USB
326	4-651-989-51	SPACER (MBX)
327	2-102-944-01	SPRING HEATSINK
328	2-050-130-01	STAND (OFF)
331	2-580-891-01	SHEET MBX-OPT
333	2-580-416-01	SHEET PHASE CHANGE
334	2-580-397-01	SHEET BOTTOM 2
336	2-639-806-01	S3 SHEET SLT
B3	4-672-836-01	SCREW, M2 SPECIAL HEAD,EG GRIP
B4	4-672-834-51	SCREW, +B EG GRIP
B5	2-050-159-01	M2 SPECIAL HEAD D7,T1
B12	4-654-387-01	SCREW (MBX)
B13	4-672-834-91	SCREW, +B EG GRIP

Ref. No.	Part No.	Description	J	AM	EU	AO
302	1-479-129-11	BLUETOOTH MODULE				
303	1-825-369-11	CABLE, COAXIAL (WITH U.F.L. CON)				
305	A-1149-423-A	COMPLETE PWB MBX-146 (EXT.) (S)				
	A-1149-424-A	COMPLETE PWB MBX-146 (INT.) (S)				
309	6-708-154-01	IC HY564128021HDL-3.7-A				
	6-708-155-01	IC HY564128021HDL-3.7-A				
	6-708-614-01	IC IC HY564128021HDL-3.7-A				
	6-708-616-01	IC IC MT8HTF6484HDV-33B3				
316	6-707-258-01	IC RH8053RGE0302MSL7SA				
	6-707-259-01	IC RH8053RGE0302MSL7SB				
	6-707-260-01	IC RH8053RGE0412MSL7SM				
	6-707-261-01	IC RH8053RGE0402MSL7SL				
	6-708-113-01	IC RH8053RGE0512MSL7VB				
	6-708-558-01	IC RH8053RNC0211MSL8MM				
325	1-751-384-71	WIRELESS LAN CARD				
	1-789-085-51	CARD WIRELESS LAN				
332	2-592-235-01	TAPE FERRITE SHORT				
335	2-580-413-01	GFX SPACER				


- This parts list contains two different types of parts.
The first type is the parts that are common to all models.
The other type is the parts that are different depending on each model.
- As for the S94PS, check the Page 4-2 of "How to identify the VGN-S94PS" for S94PS, then refer to the Parts list.
- When change the CPU (ref. 316), refer to "Replacing the CPU" in CHAPTER 5.

- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- S94PSは4-2ページの「VGN-S94PSの判別方法」を確認してから、部品表をご参照ください。
- CPU (Ref. 316) を交換する際には、CHAPTER 5の「Replacing the CPU」をご参照下さい。

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

B-1. Bottom



Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S55HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

B-1. Bottom

Ref. No.	Part No.	Description
13	4-662-881-02	CUSHION, KEY BOARD
503	X-4626-768-2	ASSY ESCUTCHEON L
505	X-2048-427-5	ASSY HOUSING BOTTOM
506	2-638-896-01	S3 LID DIMM
507	2-024-006-01	BRACKET DC JACK
508	2-638-897-01	S3 BRACKET HDD
509	2-657-864-01	S3 BRACKET KENJINTON
* 510	4-683-231-02	BRACKET OPT L
511	2-548-551-01	BRACKET OPT R
512	2-638-898-01	S3 BRACKET PCCARD
513	4-683-192-01	BRACKET VGA
514	1-831-353-11	CABLE, FLEXIBLE FLAT(22PIN)
515	1-831-350-11	CABLE, FLEXIBLE FLAT(50PIN)
517	A-1149-426-A	\$ COMPLETE PWB CNX-343 (S)
518	A-1149-425-A	\$ COMPLETE PWB CNX-342 (S)
519	1-818-398-21	CONNECTOR, FPC WITH PC CARD
520	X-2048-429-2	& ASSY LID WLAN
524	2-548-830-02	ESCUTCHEON R
526	4-683-197-01	& FOOT
527	1-963-592-11	HARNESS,CONNECTOR WITH
530	1-830-171-11	CABLE, FLEXIBLE POLYIMIDE CABL
531	4-683-188-01	RUBBER DOOR MODEM
532	4-683-186-01	RUBBER DOOR USB
534	2-023-591-02	SHEET HDD
535	2-059-467-02	SHEET OPT
539	1-694-760-21	JACK, SMALL TYPE
540	1-694-760-41	JACK, SMALL TYPE
542	4-659-711-02	SHEET (BOSS)
543	2-178-741-01	SHEET 35X25
544	2-548-831-11	ESCUTCHEON MS
545	2-656-470-01	S3 CUSHION SLT
546	2-651-246-01	COVER (FIN)
547	2-657-794-01	S3 SHEET BOTTOM
1022	-	FILAMENT TAPE 12X30
B1	4-672-834-71	& SCREW, +B EG GRIP
B4	4-672-834-51	SCREW, +B EG GRIP
B6	4-674-716-01	SCREW (NO.4-40) (UNC)
B7	4-671-538-01	SCREW(M2X4), SPECIAL HEAD
B8	4-672-839-01	HEAD, M3 FLAT
B9	4-673-648-01	& GRIP, M2 (+B) (EG)
B10	2-050-180-01	+SCREW,O2 +SPECIAL HEAD

Ref. No.	Part No.	Description	S540PS	S94PS	J	AM	EU	AO
501	X-2024-807-1	ASSY BEZEL OPT COMBO						
	X-2055-734-1	ASSY BEZEL OPT LTRV DL						
Δ (MA)	A-1152-822-A	\$ HDD (MHV20R0BH-40GB) (S)						
Δ (MA)	A-1105-815-A	\$ HDD (40GB HTS541060) (S)						
	A-1105-814-A	\$ HDD (60GB HTS541060) (S)						
	A-1105-802-A	\$ HDD (MHV20R0BH-40GB) (S)						
	A-1105-813-A	\$ HDD (80GB HTS541060) (S)						
	A-1152-824-A	\$ HDD (MHV20R0BH-80GB) (S)						
	A-1152-825-A	\$ HDD (MHV210R0BH-120GB) (S)						
	A-1148-381-A	\$ HDD (ST9120821AS-120GB) (S)						
	A-1148-380-A	\$ HDD (ST9120821AS-120GB) (S)						
516	1-797-054-21	\$ COMBO DRIVE (UDJAY8.9 MM)						
	1-797-272-11	\$ DVD-RW(UJ-832B 9.5MM)						
	1-797-273-11	\$ DVD-RW(UJ-832B 9.5MM)						
538	A-1181-385-A	\$ COMPLETE PWB IFX-331 (S)						


- This parts list contains two different types of parts.
The first type is the parts that are common to all models.
The other type is the parts that are different depending on each model.
- As for the S94PS, check the Page 4-2 of "How to identify the VGN-S94PS" for S94PS, then refer to the Parts list.

- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- S94PSは4-2ページの"VGN-S94PSの判別方法"を確認してから、部品表をご参照ください。

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S55HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

L-1. LCD 13.3-inch WXGA (Brighter) **– Made by TO –**



Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S55HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)


***L-1. LCD 13.3-inch WXGA (Brighter)
– Made by TO –***

<u>Ref. No.</u>	<u>Part No.</u>		<u>Description</u>
13	4-662-881-02		CUSHION, KEY BOARD
1001	A-1133-221-A	\$ #	LCD UNIT(13.3 WXGA) (S)
* 1002	4-683-218-01		BRACKET LCD L
* 1003	4-683-219-01		BRACKET LCD R
1004	4-673-031-01		COPPER TAPE(LCD)
1010	4-683-225-03		HINGE L
1011	4-683-226-03		HINGE R
1013	1-479-155-21		INVERTER UNIT
1015	1-963-526-11		LCD HARNESS
1017	2-024-668-01		MAGNET (LID)
1018	2-067-394-01		SHEET CABLE WLL
1019	1-754-331-22		ANTENNA (2.4/5GHZ FOR LEFT)
1020	1-754-331-12		ANTENNA (2.4/5GHZ FOR RIGHT)
1022	-		FILAMENT TAPE 12X30
B3	4-672-836-01	<&>	SCREW, M2 SPECIAL HEAD,EG GRIP
B4	4-672-834-51	<&>	SCREW, +B EG GRIP
B7	4-671-538-01		SCREW(M2X4), SPECIAL HEAD

Ref No.	Part No.	Description	J			AM			EU			AO																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																				
			SS4RS	SS4RS (20190212)	SS4S	SS50PB	SS50PB	SS50PB	SS50PB	SS50PB	SS50PB	SS50PB	SS50PB	SS50PB																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																		
	1005	4-683-220-11 & COVER DISPLAY SCREW LO (SILVER)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●</

- This parts list contains two different types of parts.
The first type is the parts that are common to all models.
The other type is the parts that are different depending on each model.
- As for the S94PS, check the Page 4-2 of "How to identify the VGN-S94PS"
for S94PS, then refer to the Parts list.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- S94PSは4-2ページの"VGN-S94PSの判別方法"を確認してから、部品表をご参照ください。

L-2. LCD 13.3-inch WXGA



Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580B/S580BH/S580P (AM)
VGN-S55HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

L-2. LCD 13.3-inch WXGA

Ref. No.	Part No.	Description
13	4-662-881-02	CUSHION, KEY BOARD
* 1002	4-683-218-01	BRACKET LCD L
* 1003	4-683-219-01	BRACKET LCD R
1004	4-673-031-01	COPPER TAPE(LCD)
1010	4-683-225-03	HINGE L
1011	4-683-226-03	HINGE R
1013	1-479-155-21	INVERTER UNIT
1015	1-963-526-11	LCD HARNESS
1017	2-024-668-01	MAGNET (LID)
1018	2-067-394-01	SHEET CABLE WLL
1019	1-754-331-22	ANTENNA (2.4/5GHZ FOR LEFT)
1020	1-754-331-12	ANTENNA (2.4/5GHZ FOR RIGHT)
1022	-	FILAMENT TAPE 12X30
1101	A-1133-220-A	\$ # LCD UNIT(13.3 WXGA) NML (S)
B3	4-672-836-01	<&> SCREW, M2 SPECIAL HEAD,EG GRIP
B4	4-672-834-51	<&> SCREW, +B EG GRIP
B7	4-671-538-01	SCREW(M2X4), SPECIAL HEAD


Ref. No.	Part No.	Description	J	S94PS	S94S
1005	4-683-220-11	& COVER DISPLAY SCREW LO (SILVER)	●	●	
	4-683-220-21	& COVER DISPLAY SCREW LO (BLACK)	●	●	
1006	4-683-221-11	& COVER DISPLAY SCREW UP (SILVER)	●	●	
	4-683-221-21	& COVER DISPLAY SCREW UP (BLACK)	●	●	
1007	4-683-222-11	COVER HINGE L (SILVER)	●	●	
	4-683-222-21	COVER HINGE L (BLACK)	●	●	
1008	4-683-223-12	COVER HINGE R (SILVER)	●	●	
	4-683-223-21	COVER HINGE R (BLACK)	●	●	
1009	4-683-224-11	& CUSHION BEZEL (SILVER)	●	●	
	4-683-224-21	& CUSHION BEZEL (BLACK)	●	●	
1012	4-683-217-11	HOUSING BEZEL (SILVER)	●	●	
	4-683-217-21	HOUSING BEZEL (BLACK)	●	●	
1015	2-954-527-01	LABEL ID (J) (BLACK)	●	●	
	2-954-527-11	LABEL ID (J) (SILVER)	●	●	
	2-954-527-21	LABEL ID (J) (SILVER)	●	●	
	2-954-527-31	LABEL ID (J) (SILVER)	●	●	
1018	A-1101-121-A	\$ ASSY DISPLAY (S)	●	●	
	A-1099-489-A	\$ ASSY DISPLAY SILVER (S)	●	●	

- This parts list contains two different types of parts.
The first type is the parts that are common to all models.
The other type is the parts that are different depending on each model.
- As for the S94PS, check the Page 4-2 of "How to identify the VGN-S94PS" for S94PS, then refer to the Parts list.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- S94PSは4-2ページの"VGN-S94PSの判別方法"を確認してから、部品表をご参照ください。

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

L-3. LCD 13.3-inch WXGA (Brighter) [MA]
– Made by SH –



Sony Confidential

VGN-S54B/S94PS/S94S (J)
 VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
 VGN-S55HP/S5M/S5VP/S5XP (EU)
 VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

L-3. LCD 13.3-inch WXGA (Brighter) [MA]



– Made by SH –

Ref. No.	Part No.	Description
13	4-662-881-02	CUSHION, KEY BOARD
* 1002	4-683-218-01	BRACKET LCD L
* 1003	4-683-219-01	BRACKET LCD R
1004	4-673-031-01	COPPER TAPE(LCD)
1005	4-683-220-11	& COVER DISPLAY SCREW LO [SILVER]
1006	4-683-221-11	& COVER DISPLAY SCREW UP [SILVER]
1007	4-683-222-11	COVER HINGE L [SILVER]
1008	4-683-223-12	COVER HINGE R [SILVER]
1009	4-683-224-11	& CUSHION BEZEL [SILVER]
1010	4-683-225-03	HINGE L
1011	4-683-226-03	HINGE R
1012	4-683-217-11	HOUSING BEZEL [SILVER]
1013	1-479-155-21	INVERTER UNIT
1014	2-649-977-31	LABEL ID (E)
1016	A-1099-489-A	\$ ASSY DISPLAY SILVER (S)
1017	2-024-668-01	MAGNET (LID)
1018	2-067-394-01	SHEET CABLE WLL
1019	1-754-331-22	ANTENNA (2.4/5GHZ FOR LEFT)
1020	1-754-331-12	ANTENNA (2.4/5GHZ FOR RIGHT)
1021	1-400-255-11	FERRITE CORE
1022	-	FILAMENT TAPE 12X30
1023	1-500-863-11	FERRITE CORE
1201	A-1124-255-A	\$ # LCD UNIT (13.3 WXGA SH) BR (S)
1202	1-963-526-21	LCD HARNESS
B3	4-672-836-01	<&> "SCREW, M2 SPECIAL HEAD,EG GRIP"
B4	4-672-834-51	<&> "SCREW, +B EG GRIP"
B7	4-671-538-01	"SCREW(M2X4), SPECIAL HEAD"

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)



A-1. Accessories

2001
AC Adaptor2007
Power Cord


2014 Power Cord




→ 2002
Conversion Plug
3P Adaptor

2003
Battery2004
L Battery


→ **2009**
Power-supply
Cord




→ **2015**
Power Cord




→ **2016**
Power Cord



→ **2018**
Power Cord



2019 Power Cord



			J		AM				EU			AO			
			SS40S	SS40PS	SS40PS+ (281199212)	SS40PS+ (281199212)	SS40PS+ (281199212)	SS40PS+ (281199212)	SS40PS+ (281199212)	SS40PS+ (281199212)	SS40PS+ (281199212)	SS40PS+ (281199212)	SS40PS+ (281199212)	SS40PS+ (281199212)	SS40PS+ (281199212)
Ref.No.	Part No.	Description													
	2001														
	1-478-116-21	\$ & AC ADAPTOR	●	●	●	●	●	●	●	●	●	●	●	●	●
	1-479-116-51	\$ & ADAPTOR AC	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)	2002	1-770-019-61													
	2003	A-1072-505-B	●	●	●	●	●	●	●	●	●	●	●	●	●
	A-1072-505-B	\$ & BATTERY PACK BP52 (J) (S)	●	●	●	●	●	●	●	●	●	●	●	●	●
	A-1072-505-B	\$ & BATTERY PACK BP52 (U) (S)	●	●	●	●	●	●	●	●	●	●	●	●	●
	A-1072-507-B	\$ & BATTERY PACK BP52 (E) (S)	●	●	●	●	●	●	●	●	●	●	●	●	●
	2004	A-1072-508-B	●	●	●	●	●	●	●	●	●	●	●	●	●
	A-1072-508-B	\$ & BATTERY PACK BPL2 (J) (S)	●	●	●	●	●	●	●	●	●	●	●	●	●
	A-1072-509-B	\$ & BATTERY PACK BPL2 (U) (S)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)	2007	1-825-237-21													
	2009	1-827-481-21													
		\$ & POWER-SUPPLY CORD	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)	2014	1-827-845-21													
		\$ & CORD, POWER	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)	2015	1-827-846-31													
		\$ & CORD, POWER	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)	2016	1-827-947-21													
		\$ & CORD, POWER	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)	2018	1-824-010-41													
		\$ & CORD, POWER	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)	2019	1-790-932-81													
		\$ & CORD, POWER	●	●	●	●	●	●	●	●	●	●	●	●	●
		1-816-429-12													
		\$ & (UK) PHONE PLUG (GB)	●	●	●	●	●	●	●	●	●	●	●	●	●
		2-852-624-01													
		\$ & Instruction Manual (XP Professional XP Home Edition)	●	●	●	●	●	●	●	●	●	●	●	●	●
		2-852-633-11													
		\$ & WELCOME MAT (U/D)	●	●	●	●	●	●	●	●	●	●	●	●	●
		2-852-635-11													
		\$ & WELCOME MAT (U/W)	●	●	●	●	●	●	●	●	●	●	●	●	●
		2-852-934-11													
		\$ & LEGAL SAFETY (U/D)	●	●	●	●	●	●	●	●	●	●	●	●	●
		2-852-936-11													
		\$ & LEGAL SAFETY (U/W)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-854-113-01													
		\$ & TROUBLE GUIDE ML MAJOR (D)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-854-113-11													
		\$ & TROUBLE GUIDE ML MINOR (D)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-852-329-11													
		\$ & TROUBLESHOOTING GUIDE(G/D)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-852-329-31													
		\$ & TROUBLESHOOTING GUIDE(G/D)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-854-119-01													
		\$ & REGULATORY BOOKLET ML (D)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-851-664-01													
		\$ & EULA (TH) (J/D)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-852-331-11													
		\$ & SAFETY REGULATIONS (I/G/D)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-852-331-21													
		\$ & SAFETY REGULATIONS (I/G/D)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-852-349-11													
		\$ & SPEC. SHEET (G/D)	●	●	●	●	●	●	●	●	●	●	●	●	●
△ (MA)		2-852-349-31													
		\$ & SPEC. SHEET (G/D)	●	●	●	●	●	●	●	●	●	●	●	●	●

- This parts list contains two different types of parts.
The first type is the parts that are common to all models.
The other type is the parts that are different depending on each model.
- As for the S94PS, check the Page 4-2 of "How to identify the VGN-S94PS" for S94PS, then refer to the Parts list.
- この部品表は、機種共通の部品と、機種によって使い分けが必要な部品に分かれています。
- S94PSは4-2ページの"VGN-S94PSの判別方法"を確認してから、部品表をご参照ください。

CHAPTER 5.


OTHER

5-1. The Barcode Label


The hatched portion of the barcode is used as the repair data.

バーコードラベルの網掛け部は、修理データとして使用いたします。


[MBX-146 Board]
(Side A)




[MBX-146 Board]
(Side B)




[LCD Unit]
(Rear)




[Keyboard Unit]
(Rear)




[Drive]
(Rear)



[W-LAN Card]
(Top)




[W-LAN Card]
(Rear)




[Memory]
(Top)




[HDD (FUJITSU)]
(Top)



[HDD (HITACHI)]
(Top)



[MODEM Card]
(Rear)



A : Part No.
B : Serial No.
C : Revision No.
D : Maker Barcode
E : Global User ID (iLink)
F : Mac Address

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)


5-2. Replacing the CPU

Note: We have two kinds of CPU for this set, and either of them is used.
Two kinds of CPU have differences in the lock position and the unlock position.

1. Socket configuration 1


1. How to remove the CPU

- ① Rotate the lock with a flat-blade screwdriver toward the unlock position shown in the figure.
- ② Remove up the CPU.



2. How to install the CPU

- ① Position the mark on the CPU to the mark on the CPU socket and put in all pins to the holes on the CPU socket.
- ② Pressing two corners marked with ○ in the figure, rotate the lock with a flat-blade screwdriver toward the lock position.




Note: Lock the CPU properly, or operation becomes unstable.

2. Socket configuration 2


1. How to remove the CPU

- ① Rotate the lock with a flat-blade screwdriver toward the unlock position shown in the figure.
- ② Remove up the CPU.



2. How to install the CPU

- ① Position the mark on the CPU to the mark on the CPU socket and put in all pins to the holes on the CPU socket.
- ② Pressing two corners marked with ○ in the figure, rotate the lock with a flat-blade screwdriver toward the lock position.



Note: Lock the CPU properly, or operation becomes unstable.

Sony Confidential

VGN-S54B/S94PS/S94S (J)
VGN-S550P/S560P/S570P/S580B/S580BH/S580P (AM)
VGN-S5HP/S5M/S5VP/S5XP (EU)
VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)



VGN-S54B/S94PS/S94S (J)

VGN-S550P/S560P/S570P/S580/S580B/S580BH/S580P (AM)

VGN-S5HP/S5M/S5VP/S5XP (EU)

VGN-S54GP/S55C/S55CP/S55SP/S56C/S56CP/S56GP/S57SP/S58CP/S58GP/S59CP (AO)

List of VGN-S Series (As of September, 2005)

Service Manual Part No.	Model Name			
	J	AM	EU	AO
9-876-369-XX	VGN-S50B	VGN-S150	VGN-S1HP	VGN-S16C
	VGN-S70B	VGN-S150F	VGN-S1VP	VGN-S16GP
	VGN-S90PS*	VGN-S150FP	VGN-S1XP	VGN-S16LP
	VGN-S90S*	VGN-S150P		VGN-S16SP
		VGN-S170*		VGN-S16TP
9-876-391-XX	VGN-S51B	VGN-S240P	VGN-S2HP	VGN-S25C
	VGN-S61PZ	VGN-S250F	VGN-S2HRP	VGN-S26C
	VGN-S71PB	VGN-S250FP	VGN-S2VP	VGN-S26GP
	VGN-S91PS*	VGN-S260	VGN-S2XP	VGN-S26LP
	VGN-S91S*	VGN-S260P	VGN-S2XRP	VGN-S26SP
9-876-402-XX	VGN-S52B/S	VGN-S350F		VGN-S36GP/S
	VGN-S62PS/S*	VGN-S350FP		VGN-S36LP/S
	VGN-S62PSY*	VGN-S360		VGN-S36SP/S
	VGN-S62S/S*	VGN-S360P		VGN-S36TP/S
		VGN-S370F		VGN-S37C/B
9-876-403-XX	VGN-S72PB/B	VGN-S380*	VGN-S3HP	VGN-S38GP/B
	VGN-S92PS/S*	VGN-S380B	VGN-S3VP	VGN-S38LP/B
	VGN-S92PSY*	VGN-S380P*	VGN-S3XP	VGN-S38SP/B
	VGN-S92S/S*			VGN-S38TP/B
9-876-417-XX	VGN-S53B/S	VGN-S430P/S	VGN-S4HP/B	VGN-S43LP/S
	VGN-S63PZ/B	VGN-S450FP	VGN-S4HRP/B	VGN-S44TP/B
	VGN-S73PB/B	VGN-S460/B	VGN-S4M/S	VGN-S45C/S
	VGN-S93PS/S*	VGN-S460F	VGN-S4VP/B	VGN-S45CP/S
	VGN-S93PSY*	VGN-S460P/B	VGN-S4XP/B	VGN-S45LP/S
9-876-431-XX	VGN-S54B-S	VGN-S550P/S	VGN-S5HP/B	VGN-S54GP/S
	VGN-S94PS	VGN-S560P/B	VGN-S5M/S	VGN-S55C/S
	VGN-S94PS*	VGN-S570P/S	VGN-S5VP/B	VGN-S55CP/S
	VGN-S94S*	VGN-S580*	VGN-S5XP/B	VGN-S55SP/S
		VGN-S580BH*		VGN-S56C/B
9-876-431-XX		VGN-S580P*		VGN-S56C/S
				VGN-S56CP/B
				VGN-S56GP/S
				VGN-S56SP/S
				VGN-S57SP/B
9-876-431-XX				VGN-S58CP/B
				VGN-S58GP/B
				VGN-S58SP/B
				VGN-S59CP/B
				VGN-S59GP/B

* : CTO Model
: Additional Models

This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation.

本マニュアルの一部、または全部について、無断でデータの複製、複写、転載することを禁じます。

Revision History

Suffix	Ver.	Date	Contents	QM No.
-01	Ver. 1	2005.09.01	First Edition	
-02	Ver. 2	2005.09.28	 Front Page (Model Lineup), Page 3, Page 1-1 to 1-2, Page 4-1, Page 4-4, Page 4-6, Page 4-8, Page 4-10, Page 4-13 to 4-15, Back Cover	N2005_048AK
<Remarks>				